

# AllEdge Premium –Aluminium Installation Instructions

## Set Out

Mark out the area. Use a marker spray or something similar and dig a 100mm deep trench.



## Laying the Edging

If necessary cut the edging to length using a hacksaw or angle grinder.



Slide the connector/stake fixing plates into position along the edging.



Lay the edging in place ensuring the smooth side is the side most visible once the installation is complete. Ensure all edgings are positioned the same way around choosing from a square or rounded top finish.



Reposition the connector plates if necessary and hammer the stakes down through the loops in the back of the plate. **Do not fully fix the stakes at this point**, just enough to hold the edging in position. Leave the last connector plate unfixed as you will need this to connect the next length.

## Connecting the Edging

The last connector on your edging should be used to connect the next length. Simply slide the next length onto the connector with half of the connector overlapping each edging length. Continue joining and fixing, once satisfied with complete layout.

## Cutting and creating corners

Either cut using an angle grinder/hacksaw or secure the edging to a workbench (or similar) and bend to 90°. Scoring the edging using an angle grinder can assist in this.

