

Borderline Steel Edging

Installation Instructions

Setting Out

Mark out the area to Edge (using a spray marker or similar) and dig a 100mm or 150mm deep trench.



Laying the Edging

Put the edging in place making sure the stakes are on the side of the edging less likely to be seen. Half fix the stakes through the loops in the back of the edging. Do not fully fix yet.



Connecting the edging

Join the edgings as shown and lightly stake. Continue positioning and staking your edging until installation is complete.

Once you are satisfied with the end result fully fix the stakes down below the top of the edge.



Cutting & creating corners

Simply cut the edging using an angle grinder or hacksaw.

Corners can be achieved by securing the edging to a workbench or something similar and simply bending to 90 degrees (scoring the edging using an angle grinder can assist in this).



These instructions are for guidance only and the installer is responsible to use their discretion to install the products in the best possible way for their respective application. English Woodlands will not be held liable for product failure or poor performance as a result of poor quality installation.