

Rite Edge Installation



Step 1

Dig a small trench around 5cm wide and 10 cm deep in the exact position you require your new edge.

Step 2

Now form the RITE-EDGE to the shape and design you require including the 5cm (approx) overlap joints. This can now be placed into the trench you formed for the edge, making sure the stake pockets are located towards the lawn side

Step 3

Check the exact height for the top of the RITE-EDGE which should be just above true ground level (approx 2-6mm) but beneath the required cut grass level.

Step 4

If you are now happy with the shape and the height, add the fixing stakes and drive fully home.

Step 5

A simple back filling on the sides of your RITE-EDGE completes your RITE-EDGE installation.

Helpful Hint

Recommended min 50mm overlap between joints.

For a flush joint along entire length joiners should be used, these are purchased separately.

Avoid forming curves and bends at stake locations as it will be more difficult to pass stakes through.

When making cuts use sharp scribe for saw to follow.

Tools Needed: Spade, Hacksaw, Hammer/Mallet, Gloves, Eye protection

